
Things you need

MDTraj, cctbx (The Computational Crystallography Toolbox)

https://github.com/lanl/lunus/blob/master/lunus/command_line/xtr

aj.py

• A reference structure (PDB)



Align your trajectory to the reference structure

- Use MDTraj (superpose function) to align the trajectory to the reference structure (e.g., crystal structure).
- Optional: only using a subset of the structure (e.g., heavy atoms, backbone).
- Save the first frame as a separate PDB file (after alignment).

Calculate the electron densities


- python xtraj.py traj=aligned.xtc top=first.pdb first=0 last=12000
- Optional:
- python xtraj.py traj=aligned.xtc top=first.pdb selection="water" first=0 last=12000 fcalc=water_fcalc.mtz icalc=water_icalc.mtz diffuse=water_diffuse.hkl
- One more thing: replace "MODEL 0" with "MODEL 1" in the pdb file (required by Coot)

To visualize the results/compare with experiment, you need...


Coot and/or Phenix




Crystal structures and electron density



Use Coot to visualize the results





Successfully read coordinates file /Volumes/Macintosh HD/Volumes/backup/projects/blues_water/electro/2xab/2xab.pdb. Molecule number 2 created.